

Heathfield&Co

Installation Guide

CEILING LIGHT | MAYA 4 VERTICAL



General Notes


- Before carrying out installation, please ensure that you have read and understood this document carefully.
- This fitting is low voltage and must be connected to a constant voltage LED driver when installing on a mains voltage circuit. Do not connect this fitting directly to a mains voltage circuit.
- The LED driver is supplied and contained within the ceiling rose.
- This fitting contains an integrated LED light source. Do not attempt to replace the lamp. In case of failure, please contact our sales team.
- This fitting is suitable for dry, indoor use only.
- Switch off electricity and ensure the correct wiring procedure & regulations have been checked with a qualified electrician.
- Ensure the fitting is being fixed to a suitable surface, strong enough to support the weight of the product.
- Ensure that suitable fixings are used - additional fixing screws are not included.
- The ceiling mount and fixing screws are supplied already attached to the fitting.
- Save these instructions for future reference.
- If you have any additional questions, please contact our sales team.

Caution

Installation of this fitting must be carried out by a qualified electrician.

Warning

Electricity must be switched off at the mains fuse box before installing this fitting.



Fan Shades
x4



Ceiling Mount
x1



Fixing Screws
x2



Maya 4V
x1

H&
CO


LIGHT BEYOND DESIGN

www.heathfield.co.uk | +44 (0) 1732 350450 | sales@heathfield.co.uk
Unit 1, Priory Road, Tonbridge, Kent, TN9 2AF, United Kingdom. © 2026 Heathfield & Co. All rights reserved.

Heathfield&Co


Installation Guide

CEILING LIGHT | MAYA 4 VERTICAL






STEP 1

- Switch off the electricity at the mains fuse box. Turning off the power at the switch is not sufficient.
- Remove the 2x fixing screws to separate the ceiling mount from the ceiling rose.



STEP 2

- Fix the ceiling mount to the ceiling using appropriate fixings.
- Make electrical connections, following the below wiring diagram. Please note you will need to hold the weight of the pendant while connecting the wires.



STEP 3

- Offer the ceiling light up to the ceiling mount & screw the fixing screws into the ceiling rose.

H&
CO


LIGHT BEYOND DESIGN

www.heathfield.co.uk | +44 (0) 1732 350450 | sales@heathfield.co.uk
Unit 1, Priory Road, Tonbridge, Kent, TN9 2AF, United Kingdom. © 2026 Heathfield & Co. All rights reserved.

Heathfield&Co


Installation Guide

CEILING LIGHT | MAYA 4 VERTICAL




STEP 4

- Remove the grub screw located in the clamp ball.



STEP 5

- Place the fan shade onto the bottom of the ceiling light and move it up until it has reached a clamp.
- Slide the fan shade into the clamp ball, and secure using the grub screw.
- Repeat with the other clamps and fan shades.



STEP 6

- Move and position the fan shades until you have reached your desired outcome.
- Switch the power back on.

H&
CO


LIGHT BEYOND DESIGN

www.heathfield.co.uk | +44 (0) 1732 350450 | sales@heathfield.co.uk
Unit 1, Priory Road, Tonbridge, Kent, TN9 2AF, United Kingdom. © 2026 Heathfield & Co. All rights reserved.

Heathfield&Co

Installation Guide

CEILING LIGHT | MAYA 4 VERTICAL



Dimensions in mm and approximate.

H&
CO

LIGHT BEYOND DESIGN

www.heathfield.co.uk | +44 (0) 1732 350450 | sales@heathfield.co.uk
Unit 1, Priory Road, Tonbridge, Kent, TN9 2AF, United Kingdom. © 2026 Heathfield & Co. All rights reserved.