

Heathfield&Co

Installation Guide

WALL LIGHT | ENZO HEADBOARD



General Notes



- Before carrying out installation, please ensure that you have read and understood this document carefully.
- This fitting is low voltage and must be connected to a constant voltage LED driver when installing on a mains voltage circuit. Do not connect this fitting directly to a mains voltage circuit.
- The LED driver is supplied and contained within in the backbox.
- This fitting contains an integrated LED light source. Do not attempt to replace the lamp. In case of failure, please contact our sales team.
- This fitting is suitable for dry, indoor use only.
- Switch off electricity and ensure the correct wiring procedure & regulations have been checked with a qualified electrician.
- Ensure the fitting is being fixed to a suitable surface, strong enough to support the weight of the product.
- Ensure that suitable fixings are used - additional fixing screws are not included.
- The liner plate and fixing screws are supplied already attached to the fitting.
- Save these instructions for future reference.
- If you have any additional questions, please contact our sales team.

Caution

Installation of this fitting must be carried out by a qualified electrician.

Warning


Electricity must be switched off at the mains fuse box before installing this fitting.



Back Box
x1



Fixing Screws
x1



Enzo Headboard
x1

H&
CO


LIGHT BEYOND DESIGN

www.heathfield.co.uk | +44 (0) 1732 350450 | sales@heathfield.co.uk
Unit 1, Priory Road, Tonbridge, Kent, TN9 2AF, United Kingdom. © 2026 Heathfield & Co. All rights reserved.

Heathfield&Co


Installation Guide

WALL LIGHT | ENZO HEADBOARD




STEP 1

- Switch off the electricity at the mains fuse box. Turning off the power at the switch is not sufficient.
- Lift the adjustable head of the light upwards.
- Remove the 1x fixing screw to separate the wall light from the back box.



STEP 2

- Place the back box to the headboard or wall and draw around it to create the outline of the hole you will cut out. You can also see the cutting guide on the last page of this document.



STEP 3

- Thread the wire through the opening in the back box.
- Push the back box into the hole in the wall.

H&
CO


LIGHT BEYOND DESIGN

www.heathfield.co.uk | +44 (0) 1732 350450 | sales@heathfield.co.uk
Unit 1, Priory Road, Tonbridge, Kent, TN9 2AF, United Kingdom. © 2026 Heathfield & Co. All rights reserved.

Heathfield&Co


Installation Guide

WALL LIGHT | ENZO HEADBOARD





STEP 4

- Fix the back box onto the wall using the appropriate fixings.



STEP 5

- Make the electrical connections, following the below wiring diagram.
- Offer the wall light up to the back box & screw the fixing screw into the front of the light.



STEP 4

- Push the adjustable head back down.
- Switch the power back on.

H&CO


LIGHT BEYOND DESIGN

www.heathfield.co.uk | +44 (0) 1732 350450 | sales@heathfield.co.uk
Unit 1, Priory Road, Tonbridge, Kent, TN9 2AF, United Kingdom. © 2026 Heathfield & Co. All rights reserved.

Heathfield&Co

Installation Guide

WALL LIGHT | ENZO HEADBOARD



Dimensions in mm and approximate.

H&
CO


LIGHT BEYOND DESIGN

www.heathfield.co.uk | +44 (0) 1732 350450 | sales@heathfield.co.uk
Unit 1, Priory Road, Tonbridge, Kent, TN9 2AF, United Kingdom. © 2026 Heathfield & Co. All rights reserved.

Heathfield&Co

Installation Guide

WALL LIGHT | ENZO HEADBOARD



Cutting Guide

Dimensions in mm and approximate.

H&
CO

LIGHT BEYOND DESIGN

www.heathfield.co.uk | +44 (0) 1732 350450 | sales@heathfield.co.uk
Unit 1, Priory Road, Tonbridge, Kent, TN9 2AF, United Kingdom. © 2026 Heathfield & Co. All rights reserved.