

Heathfield&Co

Installation Guide

WALL LIGHT | ENZO READING



General Notes



- Before carrying out installation, please ensure that you have read and understood this document carefully.
- This fitting is low voltage and must be connected to a constant voltage LED driver when installing on a mains voltage circuit. Do not connect this fitting directly to a mains voltage circuit.
- The LED driver is supplied and contained within the backbox.
- This fitting contains an integrated LED light source. Do not attempt to replace the lamp. In case of failure, please contact our sales team.
- This fitting is suitable for dry, indoor use only.
- Switch off electricity and ensure the correct wiring procedure & regulations have been checked with a qualified electrician.
- Ensure the fitting is being fixed to a suitable surface, strong enough to support the weight of the product.
- Ensure that suitable fixings are used - additional fixing screws are not included.
- The liner plate is supplied already attached to the fitting.
- Save these instructions for future reference.
- If you have any additional questions, please contact our sales team.

Caution


Installation of this fitting must be carried out by a qualified electrician.

Warning

Electricity must be switched off at the mains fuse box before installing this fitting.



Back Plate Cap
x1



Enzo Reading
x1

H&
CO


LIGHT BEYOND DESIGN

www.heathfield.co.uk | +44 (0) 1732 350450 | sales@heathfield.co.uk
Unit 1, Priory Road, Tonbridge, Kent, TN9 2AF, United Kingdom. © 2026 Heathfield & Co. All rights reserved.

Heathfield&Co


Installation Guide

WALL LIGHT | ENZO READING





STEP 1

- Switch off the electricity at the mains fuse box. Turning off the power at the switch is not sufficient.
- Rotate the back plate cap anticlockwise and remove it from the light.



STEP 2

- Drill a suitable hole into the wall. This is so the back of the light, including the driver, can fit. Please make sure the hole is not too big so the screw fixings can still attach to the wall.
- Make the electrical connections, following the below wiring diagram.
- Fix the liner plate to the wall using the appropriate fixings. Please note the fixing screw heads need to be thin so the bezel can sit flush onto the wall light.



STEP 3

- Place the back plate cap onto the light and reattach it by turning it clockwise.
- Switch the power back on.

H&
CO


LIGHT BEYOND DESIGN

www.heathfield.co.uk | +44 (0) 1732 350450 | sales@heathfield.co.uk
Unit 1, Priory Road, Tonbridge, Kent, TN9 2AF, United Kingdom. © 2026 Heathfield & Co. All rights reserved.

Heathfield&Co

Installation Guide

WALL LIGHT | ENZO READING



Dimensions in mm and approximate.

H&
CO

LIGHT BEYOND DESIGN

www.heathfield.co.uk | +44 (0) 1732 350450 | sales@heathfield.co.uk
Unit 1, Priory Road, Tonbridge, Kent, TN9 2AF, United Kingdom. © 2026 Heathfield & Co. All rights reserved.